



40th International Pyrotechnics Seminar



ResonantAcoustic® Mixing of PBX

S.L. Coguill and L.C. Farrar, Resodyn Acoustic Mixers,
Butte, Montana USA



Outline

- RAM Technology Overview
- Inert PBX Mixing Experiments
- Mixing Evaluation
- Value Proposition
- Live PBX Case Study

RAM Technology Overview

Laboratory Mixers



- **ResonantAcoustic[®] Mixing (RAM)**

- Non-contact mixing
- **Low-frequency**
 - 60 Hz
 - Harmonic resonance
- **High-intensity**
 - 100 X's the acceleration of gravity
- **Resonant tracking**
 - Automatic
- **Acoustic field**
 - Efficient energy distribution
 - Uniform & simultaneous micro-mixing



Production Mixers



Experimental Procedure


- Inert PBX Formulation

Weight %	Ingredient	Characteristics
7.91	HTPB	Polybutadiene
0.30	Lecithin	Thickening Agent
7.91	DOA	Plasticizer
41.49	Gypsum	Energetic Simulant
41.49	Granulated Sugar	Energetic Simulant
0.05	Blue Pigment	Inert Marker
0.03	DBTDL	Catalyst
0.71	IPDI	Curative

•Distribution A: Distribution approved for public release; distribution is unlimited.

Surrogate PBX Mix -- LabRAM

- 0.2 kg
- 12 minutes of processing time



Surrogate PBX Mix -- RAM 5

- 20 kg
- 12 minutes of processing time



Surrogate PBX Mix -- RAM 55

- 200 kg
- 14 minutes of processing time





RAM 55 Batch Mixing – PBX Surrogate

R45 Based Energetic
Surrogate in
the RAM 55



Surrogate PBX Mix RAM 5 Compared to RAM 55




RAM 5 and RAM 55 Mix Test Data

- Comparative Test Results


PLATFORM	MASS	POWER	POWER/kg
RAM 5	21 kg	4.3 kW	156 W/kg
RAM 55	204 kg	36.5 kW	137 W/kg



Mix Comparison




21 kg mix – 12 minutes




204 kg mix – 14 minutes

Mix Evaluation

- JANNAF Dog Bones Per CPIA Pub 21
- Gage Length Cross Section, 0.95 by 1.27 cm



PBX Simulant Across Platforms




Value Proposition Cost Reductions

- **Equipment and Labor Reductions**
 - Reduced equipment stations
 - Reduced processing steps
 - Reduced processing time
- **One Step Ingredient Addition**
- **Mix-in-Mold or Mix-in-Case**
 - Near net shape to minimize post-cure machining
 - Final shape : mix-in-case
- **Energy Costs Reduced**
 - Reduced mix times
 - No mix vessel heat addition required
- **Reduced Waste**

RAM 5 CASE STUDY

McAlester Army Ammunition Plant

- **Manufacture 108 Cluster Bomb Boosters for the U.S. Air Force**
- **Current Process**
 - Cut and Machine from solid round extrusion
 - Previous Cost **\$1,250** per part
- **ResonantAcoustic[®] Manufacturing Process**
 - Near-net-shape each part
 - Production capabilities of **500** per month
 - Anticipated Cost **\$450** per part



McAlester RAM 5 Installation


- Value Proposition --Net Economic Outcome/Gain
 - Saves ~\$800 per part
 - Payback < 12 months
 - Provides ability to meet current product demand



- RAM 5 for Mixing Energetics Installed and Started Up December 2013
- Energetic Manufacturing Currently in Full Production



Resodyn Acoustic Laboratory Mixer Hazardous Environment



- **Class I, Division 1; Class II, Division 2**
- **1,000 grams (2.2 lbs.) capacity**
- **Remote Operations**
- **Stainless Steel Cabinet**
- **Consolidated Mechanical, Electrical and Controls Package**

Contact Information

Scott Coguell
Senior Research Engineer
(406) 497-5229 Direct
scoguell@resodyn.com

Lawrence C. Farrar
President & CEO
(406) 497-5252 Direct
(406) 560-2596 Cell
Lawrence.Farrar@resodyn.com

Innovative Mixing Technology

***Thank you for
your attention***

***A Veteran Owned
Small Business***



UNITED STATES
DEPARTMENT OF VETERANS AFFAIRS

